



SERVICE DROP LEGEND

- E** = ELECTRICAL DROP
- W** = WATER INLET
- D** = DWV PLUMBING DROP
- G** = GAS INLET

PIER LEGEND

- = PIER MAIN BEAM
- = PIER PERIMETER
- = PIER PORCH/RECESSED ENTRY

SHEARWALL LEGEND

- = WIND ZONE 1
- = WIND ZONE 2

NOTES:

1. SEE SETUP MANUAL FOR REQUIRED PIER CAPACITY AND SPACING.
2. SEE SETUP MANUAL FOR FOOTING REQUIREMENTS.
3. SERVICE DROP LOCATIONS IDENTIFIED ARE APPROXIMATE.
4. PIERS SHALL BE LOCATED AT A MAXIMUM OF 2 FEET FROM BOTH ENDS.
5. PERIMETER PIERS OR OTHER SUPPORTS MUST BE LOCATED AS FOLLOWS: ON BOTH SIDES OF SIDEWALL EXTERIOR DOORS (SUCH AS ENTRY, PATIO AND SLIDING GLASS DOORS) AND ANY OTHER SIDEWALL OPENINGS 48" OR GREATER IN WIDTH, AND UNDER LOAD-BEARING PORCH POSTS, FACTORY INSTALLED FIREPLACES AND FIREPLACE STOVES, ETC.
6. SEE TABLE 4.2 FOR PIER CAPACITIES AT MARRIAGE LINE OPENINGS.

** REFER TO MANUFACTURER'S FLOOR PLAN (PROVIDED) FOR SHEARWALL LOCATIONS (INCLUDING ENDWALL). THESE ANCHORS MUST BE INSTALLED IN ACCORDANCE WITH THEIR LISTING.

1312 SQ.FT. (STD PLAN "CONDITIONED")



NEW VISION MANUFACTURING, LLC
1110 N Industrial RD
Madill, OK 73466

DATE:
03/26/2019

MODEL:
NV-2801
AVALOS

TITLE:

FRAME PIERS

DWG #:
NV-2801 FRAME PIER B&W

SCALE:

DRAWN BY:
MAXWELL W.

REF #	DESCRIPTION	DATE	REVISED BY:	PAGE #: